




CABINET PARTS

For Model: EL05CCXJW
(White)

REFRIGERATOR



Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)
2	4312436	Hinge, Top
3	4312437	Hinge, Bottom
4	4312438	Shim, Hinge
5	4312439	Strain Relief
6	4312440	Bushing, Hinge
7	4312399	Thermostat

Illus. No.	Part No.	DESCRIPTION
8	4312441	Knob, Thermostat
9	4312481	Control Box
10	4312443	Stud
11	4312444	Stud
12	4312445	Foot, Front
13	4312446	Power Cord
14	4312406	Cap, Leveler
15	4312447	Hole Plug


Illus. No.	Part No.	DESCRIPTION
17	4312514	Box, Junction
22	4312453	Screw
23	4312405	Leveler
24	4312454	Screw
25	4312455	Washer
26	4312482	Cover, Cabinet
27	4312407	Kit, Leg Leveler

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: EL05CCXJW

(White)



Illus. No.	Part No.	DESCRIPTION
1	4312510	Compressor
2	4312457	Base, Compressor
3	4312529	Evaporator
4	4312459	Retainer, Evaporator
5	4312496	Drier
6	4312461	Washer
7		Relay (See Overload)

Illus. No.	Part No.	DESCRIPTION
8	4312483	Overload (Includes Relay)
9	4312463	Stud, Evaporator
10	4312464	Screw
11	4312450	Screw
12	4312465	Pin, Cotter
13	4312466	Washer
14	4312530	Gasket


Illus. No.	Part No.	DESCRIPTION
REFRIGERANT CHARGE		
		2.12 oz. (R-134)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Model: EL05CCXJW

(White)




Illus. No.	Part No.	DESCRIPTION
1	4312522	Door, Freezer
2	4312468	Tray, Freezer
3	4312531	Shelf, Wire Upper
4	4312470	Tray, Ice Cube
5	4312471	Hinge, Freezer Door (2)
6	4312486	Cover, Crisper
7	4312487	Pan, Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: EL05CCXJW

(White)



Illus. No.	Part No.	DESCRIPTION
1	4312532	Panel, Exterior Door
2	4312533	Panel, Interior Door
3	4312525	Trim, Door (Short)
4	4312526	Trim, Door (Long)
5	4312520	Nameplate
6	4312454	Screw
8	4312565	Gasket, Door
9	4312479	Hole Plug
10	4312527	Trim, Door (Long)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST