

PARTS LIST

for



30" FREESTANDING SEALED GAS RANGE SELF-CLEAN OVEN

MODEL
SF386PEWW0

▲W-White



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1992 WHIRLPOOL CORPORATION

FOR SERVICE INFORMATION
SEE SERVICE (BROWN) FILMCARD(S)
182-A-2

CONTROL PANEL PARTS


For Model: SF386PEWW0



1	816748	Glass, Backguard
2	816697	Electronic Control
3	816701	Plate, Instrument Mounting
6	816702	Brace, Backguard
7		End Cap
	816696	Right
	816694	Left
8	816751	Trim, Wrapper
9	816707	Trim, Vent
10	816705	Trim, Splasher
11	816661	Shield, Rear Wall
12	816747	Button, Control, (8)
13	816749	Knob, Oven
14	816752	Retainer, Glass
15	816750	Switch, Light


COOKTOP PARTS

For Model: SF386PEWW0



1	816735	Grate
2	816717	Top, Main
3		Bracket, Hinge
	816721	Right
	816586	Left
5	816739	Panel, Manifold
6	816738	Knob, Control (4)
7	816732	Cap, Burner (Lg)
8	816553	Ring, Trim (Lg)
9	816718	Screw, Burner Mtg.
10	816545	Cap, Burner (Sm)
11	816740	Ring, Trim (Sm)


For Model: SF386PEWW0



1	816592	Burner, (Small) See Page For Further Breakdown.
2	816603	Tubing, Burner (RF)
3	816605	Tubing, Burner (RR)
4	816604	Tubing, Burner (LF)
5	816606	Tubing, Burner (LR)
6	816599	Pipe, Manifold
7	816600	Valve, Top Burner (LG)
8	816601	Valve, Top Burner (SM)
9	816598	Switch, Ignitor (4)
10	816691	Tubing, Regulator To Manifold Pipe
11	816613	Control Regulator
12	816636	Bracket, Regulator
13	816589	Burner, (Large) See Page For Further Breakdown
14	816550	Shutter (Lg)
15	816551	Shutter, (Sm)
16	816560	Seal, Burner (Sm)
17	816561	Seal, Burner (Lg)
18	816593	Plate, Burner Mounting (2)
19	816719	Screw, Mounting Plate To Burner
20	816602	Plate, Burner Tube (2)
21	816568	Screw, Burner
22	816555	Screw, Valve To Manifold


OVEN PARTS

For Model: SF386PEWW0



1	816669	Spacer, Body
2	816664	Shield, Wool
3	816651	Screw, #8-18 x 1 7/16
4	816668	Socket, Oven Lamp
5	816641	Lamp, Oven
6	816647	Retainer, Glass
7	816609	Lens, Oven Lamp
8	816611	Hinge, Oven Door (2)
9	816617	Cover, Hinge
10	816656	Shield, Heat (Upper)
11	816657	Shield, Heat (Lower)
12	816614	Cord, Power
13	816640	Switch, Latch
14	816633	Fastener, Push-On
15	816612	Clip, Spring (2)
16	816581	Back, Main
17	816649	Rod, Light
18	816608	Bumper, Front (2)
20	816671	Switch, Door
21	816587	Bracket, Light Switch
22	816662	Shield, Heat
23	816577	Clip, Wire
24	816619	Flue Box
25	816620	Gasket, Flue
26	816737	Knob, Latch
27	816635	Latch, Door
28	816634	Handle, Latch
29	816615	Cover, Plate
30	816595	Burner Box
31	816655	Shield, Main Front
32	816638	Shield, Latch
33	816660	Shield, Heat Baffle
34	816709	Panel, Side (LH)
	816708	Panel Side (RH)
35	816650	Screw, Leveler (4)
36	816670	Support, Oven Bottom
37	816618	Fastener, Cord
38	816630	Insulation, Oven Back
39	816583	Oven Bottom
41	816645	Probe, Temperature
42	816639	Spacer, (2)
43	816637	Shield, Latch
44	816653	Screw, Latch Knob
46	816627	Insulation, Front
47	816629	Insulation, Oven Wrapper
48	816585	Anti-Tip Bracket

OVEN RACK PARTS




- | | | |
|---|--------|---------------------|
| 1 | 816646 | Rack, Oven |
| 2 | 816626 | Insert, Broiler Pan |
| 3 | 816644 | Pan, Broiler |

LITERATURE PARTS

- | | |
|------------|---------------------------|
| LIT816515 | Use & Care Guide |
| LIT816516 | Installation Instructions |
| LIT3149508 | Cooking Guide |
| LIT816520 | Quick Reference Sheet |
| LIT816517 | Tech Sheet |
| LIT816521 | Wiring Diagram |
| LIT816710 | Repair Parts List |


BROILER & OVEN BURNER PARTS

For Model: SF386PEWW0



1	816582	Baffle, Broiler Burner
2	816584	Baffle, Oven Burner
3	816722	Burner, Broiler
4	816588	Burner, Oven
5	816624	Ignitor, Broiler Burner
6	816625	Ignitor, Oven Burner
7	816541	Ignitor, Module
8	816594	Mixer, Elbow
9	816689	Tubing, Valve To Mixing Elbow
10	816692	Valve, Dual
11	816690	Tubing, Valve To Regulator
12	816642	Nut, Hex (2)


COMPLETE SEALED GAS BURNER PARTS



1		Burner, Gas (Complete)
	816589	Large
	816592	Small
3	816568	Screw, Burner
4	816566	Clip, Ignitor
5		Orifice, Burner
	816567	Large
	816570	Small
6	816565	Ignitor

OVEN DOOR AND DRAWER PARTS

For Model: SF386PEWW0



1	816736	Handle, Door
2	816746	Trim, Door
3	816744	Glass, Door
6	816743	Bracket, Glass
7	816681	Glass, Heat Shield
8	816686	Shield, Heat
9	816687	Spacer, Glass
10	816679	Window, Door
11	816677	Collar, Glass
12	816682	Insulation, Door
13	816683	Liner, Oven Door
14	816652	Screw, Handle
15	816685	Seal, Oven Door
16	816711	Drawer, Utility
17	816712	Guide, Drawer
18	816754	Panel, Drawer
19	816753	Handle, Utility Drawer
20	816716	Shield, Panel
21	816713	Spacer, Handle
22	816756	Screw, 8-18 x 1/2 (4)
23	816755	Screw, 10-18 x 1/2 (2)