




COOKTOP PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)

30" Slide-In
DESIGNER STYLE
Gas Range




Illus. No.	Part No.	DESCRIPTION
1	LIT9753052	Literature Parts
	LIT9753051	Installation Instructions
	LIT9753053	Use & Care Guide
	LIT9753055	Tech Sheet
	LIT9753426	Wiring Diagram
	LIT9753502	Template, Anti-Tip
	LIT9753502	Instructions (LP Conversion)
	LIT3191638	Safer Cooking Tips
	LIT9781877	Service Instr.
	LIT9753268	Back Trim Instr.
2		Cooktop, Gas
	9781890GW	White
	9781890GB	Black
	9781890GC	Biscuit
3	9752889	Trim, Rear
5		Cap, Vent
	9753772GW	White
	9753772GB	Black
6	9752890	Trim, Side
7		Cap, Burner Large
	3191905	Grey
	3191904	Black
		Small
	3191899	Grey
	3191898	Black
11	9780265	Screw, 10-16 x 3/8
12	9752974	Support, Cooktop
13	9751629	Bracket, Pivot
15	9782000	Bracket, Rear Angle
16		Grate, Burner
	8053455	Cumberland Grey
	8053456	Black
17	9751984	Bimetal, Fan
18	341196	Thermostat, SPST
20	9751644	Screw, 10-24 x 1/2
	9781555	Speed Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	9752897PB	Panel, Control Black
	9752897PW	White
	9752897PC	Biscuit
2	9752901CB	Glass-Console Black
	9752901CW	White
	9752901CC	Biscuit
4		End Cap Left
	9781889FB	Black
	9781889FW	White
	9781889FC	Biscuit
		Right
	9781888FB	Black
	9781888FW	White
	9781888FC	Biscuit
5	9753504	Gasket, Cover
6	9752955	Cover, Control
7	9752906	Clip, Glass (2)
8		Knobs, Control (4)
	3187767	Black
	3187766	White
	9753990FC	Biscuit
9	9753503	Label-WPSI Control
15	9753639	Control, Range
16		Knob, Timer (18)
	9781954FB	Black
	9781954FW	White
	9781954FC	Biscuit
34	9780265	Screw, 10-16 x 3/8
	9780271	Screw
35	9780273	Screw, 10-16 x 3/4

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base w/Orifice
	9754183	Small (2)
	9754189	Large (2)
2	9753005	Tubing, Burner(RF)
3	9753006	Tubing, Burner(RR)
4	9753003	Tubing, Burner(LF)
5	9753004	Tubing, Burner(LR)
7	9753045	Valve, Burner Small (2)

Illus. No.	Part No.	DESCRIPTION
8	9753044	Valve, Burner Large (2)
9	9752994	Spark Switch & Harness Assembly
10	9754148	Tube, Manifold
11		Manifold
	9754116L	Left Hand
	9754116R	Right Hand
13	9754215	Electrode
14	3185829	Bolt, Valve (4)

Illus. No.	Part No.	DESCRIPTION
16		Orifice, Burner
	9753928	Small Base, 6K
	9753929	large Base, 12K
18	9751854	Tubing, Flex
21		Head, Burner
	4455979	Small
	4455981	Large
22	8281147	Screw, 8-18 x 5/8


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BROILER & OVEN BURNER PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	9752737	Shield, Oven (2)
2	9752738	Flame Shield, Bake
3	9752980	Shield, Flame
4	9751367	Burner, Bake
6	9782065	Ignitor, Oven Burner
8	9752736GM	Pan, Oven Bottom
9	9782105	Tubing, Broil
10	9752698	Valve, Regulator Assembly
11	776593	Screw, 1/4-20x1/2
12	9781015	Tubing, Valve
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
15	9753409	Deflector, Broil
16	9752981	Burner, Broil
18	9751644	Screw, 10-24 x 1/2
19	9752984	Fitting, Broiler
20	9780265	Screw, 10-16 x 3/8
21	9781509	Screw, 8-32 x 3/8
22	9751643	Screw, #10 x 3/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
2		Trim, Door-Left
	9782003PW	White
	9782003PB	Black
	9782003PC	Biscuit
3		Trim, Door-Right
	9782004PW	White
	9782004PB	Black
	9782004PC	Biscuit
4		Trim, Door Bottom
	9781209PW	White
	9781209PB	Black
	9781209PC	Biscuit
5		Glass, Door
	9781694PW	White
	9781694PB	Black
	9781694PC	Biscuit
6		Vent, Door
	9753498GW	White
	9753498GB	Black
	9753498GC	Biscuit
	9781490	Seal, Door
		Vent Side
	9781659	Gasket, Door Vent
8		Handle, Door
	9752701PW	White
	9752701PB	Black
	9752701PC	Biscuit
9	9781449	Gasket, Door Glass
10	9782033	Hinge, Door R or L
	90296	Clip
12	9781602	Frame, Window
13	9781586	Shield Door
14	9780771	Bumper, Rubber
15	9781593	Glass, Door (2)
16	9755177	Seal, Glass
18	9754006	Insulation
19	9781600GM	Liner, Door
20	9780583	Drawer & Roller
21	9750169	Bracket, Drawer
22	9780272	Screw (4) 10 x 1/2
24		Front, Drawer
	9782108PW	White
	9782108PB	Black
	9782108PC	Biscuit
25	423713	Support, Roller
27	9750676	Retainer, Panel
	90296	Clip
28	9781502	Retainer, Glass
29	9780265	Screw, 10-16 x 3/8
30	9750693	Channel, Heat
	9754005	Insulation, Drawer Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS


For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	9753300	Vent, Burner Box
2	9750514GM	Chassis, Front
3	8935	Bulb, Oven
4	9781050	Socket, Light
5	9753011GM	Oven Liner
6	9755179	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PB	Black
	9781907PC	Biscuit
8	9780664	Shield, Insulation
9	9751789	Fan Duct, Side
10	8053421	Spark Module
11	9752975	Burner Box
12	9752735	Retainer, Insulation
13	9751653	Duct, Top
	9780265	Screw, (2)
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left 10 x 3/8
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Hinge, Receiver
20	9781904	Support Rail, Pan
21	9782051	Shield, Drawer
22	9782050	Plate, Reflectance
23	420101GM	Pan, Broiler
24	9750498	Rack, Standard (2)
26	9782081	Sensor, Oven
27	9781049	Lens, Light
28	3184533	Gasket, Lens
29	9781580	Door Switch
30	420104GM	Grill, Broiler
31	9752978	Vent, Burner Box
32	9751644	Screw, 10-24 x 1/2
33	9753067	Extension, Vent Box
34	9754004	Insulation, Wrap
35	9780265	Screw, 10-16 x 3/8
36	9780275	Screw, #8 x 3/8
37	9751808	Screw, #8 x 1
40	9754011	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back Panel, Chassis
3	9751353	Panel, Rear Cover
5	9750526	Bracket, Lock
6	9751500	Bracket, Regulator-Valve
7	9752404	Oven Lock Assembly (Includes Key #17)
8	9752409	Solenoid

Illus. No.	Part No.	DESCRIPTION
9	422222	Screw
10	424238	Washer
12	9750965	Switch, Interloc
13	9750887	Screw, (2)
14	9750888	Nut (2)
15	9750523	Rod, Lock
16	258076	Block, Terminal

Illus. No.	Part No.	DESCRIPTION
17	9752462	Single Position Device (Not Serviced)
20	98884	Screw
21	340184	Screw 10-16 x 11/2
22	423247	Screw
24	9780265	Screw, #10 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: GW395LEGQ5, GW395LEGB5, GW395LEGT5
(Designer White) (Designer Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150°c
242820	Wire, Black	14 Ga. 150°c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242829	Wire, Red	12 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242826	Wire, White	14 Ga. 150°c
242827	Wire, Yellow	14 Ga. 150°c
242832	Wire, Yellow	14 Ga. 200°c

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)
4392899	Biscuit

NOTE: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)
4392901	Biscuit

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean (1/2 Pt.)

INSULATION

9751164	Insulation, Wrap
9750221	Insulation, Rear
9751323	Insulation, Bottom

CLEANER, COOKTOP

3184477	Glass Cleaner
3183488	Scraper

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Miscellaneous

	Trim, Back Cover
9753267PB	Black
9753267PW	White
9753267PC	Biscuit

ACCESSORIES

241430	Foil, Aluminum Oven (18" X 25')
--------	---------------------------------

CONVERSION KIT

	Gas Conversion Kit
9753054	(LP)
9752717	(Natural)

LUBRICANT

261582	Grease
--------	--------

WIRING HARNESS PARTS

9782345	Harness, Wire (Main Harness)
9754289	Harness, Wire (Neutral Gas)
9752769	Harness, Wire (Dual Cooktop)
9750744	Harness, Wire (Oven Door)
9755256	Harness, Wire (Spark Module)
98997	Clip
3196520	Clip
20082084	Tie, Wire
9781055	Cord, Power
9751868	Grommet Harness(2)
9750984	Cable Hanger