


KitchenAid®

OVEN PARTS

For Models: KEBI171DBL2, KEBI171DWH2
(BLACK) (WHITE)

27" BUILT-IN ELECTRIC
SINGLE OVEN
SELF-CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEBI171DBL2, KEBI171DWH2
(BLACK) (WHITE)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1		Trim, Side
	4450844	RH Black
	4450845	RH White
	4450847	LH Black
	4450848	LH White
		Screw
	4449747	Black Model
	4449041	White
4	4448520	Bumper, Door
6	4451038	Divider, Vent
	4449809	Screw
7	4451165	Partition
	4449809	Screw
9	4449009	Tube, Vent
	4449154	Screw
11	4448972	Oven Light Assy
	4449748	Screw
14	4450416	Frame, Front
	4449040	Screw
15	4449371	Gasket, Door

Illus. No.	Part No.	DESCRIPTION
19	4450541	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451036	Shield, Latch
	4450289	Screw
23	4450051	Deflector, Latch
	4449154	Screw
24	4454710	Latch Assy
	4449809	Screw
25	4450528	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4454728	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4450026	Sensor
	4449154	Screw
31	4450819	Switch, Door
32	4449369	Vent Box Assy.
37	4450934	Thermostat (TOD) (Temp.) SPST
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
43	4450526	Base, Chassis
	4449809	Screw
49	4448933	Retainer
	4449154	Screw
50	4450544	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448458	Black Model
	4448459	White Model
	4450289	Screw
52	4450795	Vent Extension
	4449154	Screw
53	4449845	Support, Bracket
54	4451002	Spacer, Harness
	4449809	Screw


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

CONTROL PANEL PARTS

For Models: KEBI171DBL2, KEBI171DWH2
(BLACK) (WHITE)



Illus.	Part	
No.	No.	DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	Control Panel Assy. W/Membrane Switch
4451254	Black Model
4451255	White Model
2	4451033 Gasket, Control Panel
4159465	Screw
3	4448865 Microcomputer


LITERATURE PARTS

LIT4450410	Installation Instructions
LIT4450570	Use & Care Guide
LIT4454768	Tech Sheet
LIT4449264	Easy Set Guide

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEBI171DBL2, KEBI171DWH2
(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4450428	Door Liner
2	4451173	Hinge, Door
	4449743	Screw
3	4448707	Insulation, Sides
4	4449253	Glass, Inner
5	4450422	Retainer, Glass
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

6	4450361	Shield, Heat
	4449809	Screw
7	4449257	Glass, Inner (2)
9	4450813	Bracket, Handle
	4451040	Screw
10	4450836	Seal, Top
11		Handle
	4448411	Black Model
	4448412	White Model
12		Glass, Outer
	4450696	Black Model
	4450697	White Model

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

15	4450838	Seal, Sides
16	4449031	Retainer, Glass
	4449809	Screw
17	4450470	Retainer, Glass
	4449809	Screw
18		Clip, Retainer
	4450863	Black Model
	4450864	White Model
19	4448679	Insulation, Top and Bottom


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEBI171DBL2, KEBI171DWH2

(BLACK)

(WHITE)




Illus. No.	Part No.	DESCRIPTION
2	4448701	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448715	Rack, Oven
7	4448695	Element, Bake
	4449154	Screw
15	4448722	Tray, Hidden Bake
17	4450039	Cover, Bake Tray

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBI171DBL2, KEBI171DWH2
(BLACK) (WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

3	4450920	Blower
5	4450328	Transformer, Light
	4449809	Screw
6	4450366	Exhaust Duct
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

11	4449868	Block, Terminal
	3196181	Screw
13	4448551	Vent, (Control Panel)
	4450038	Screw
14	4448371	Right Side, Control Top
	4448372	Left
	4449809	Screw
	4449154	Screw
15	4450658	Back, Control
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4450553	Cover, Top Front
	4449809	Screw
19	4450545	Bracket, Blower
	4449809	Screw
21	3182384	Seal, Foam

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEB171DBL2, KEB171DWH2
(BLACK) (WHITE)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

SPLICING WIRES--25FT.

LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

WIRING HARNESS PARTS

	4450951	Harness, Wire (Door Switch)
	488366	Clamp
	4449809	Screw
	4454709	Harness, Wire (Latch)
	4450952	Conduit
	4448664	Clamp
	4450800	Screw, Ground
	4454703	Harness, Wire (Main)

Miscellaneous

	814381	Pin Hinge Kit
	814387	Roll Tape, Exhaust Duct
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST