

PARTS LIST

for



30" RANGE HOOD (VENTED)

MODEL
RH7330XLW0

▲W—White
D—New Avocado
G—Golden Harvest
N—Almond
F—Toast
M—Platinum
S—Stainless Steel
(Use With Gas Or Electric Range)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



RANGE HOOD PARTS

For Model: RH7330XLW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	830368	Damper, Complete
2	830173	Receptacle, Snap-In
3	830741	Cover, Switch Box
4	830465	Screw, 8 x 1/4
5	830737	Lampholder, Snap-In
6	830747	Screw, 8 x 3/8 (8)
7	830742	Motor Bracket (2)
8	830786	Blower Wheel, L.S.
	830785	Blower Wheel, R.S.
9	830748	Rod, Retaining
10		Cover, Blower (Includes Illus. 23)
	883007	White
	883011	New Avocado
	883010	Golden Harvest
	883008	Almond
	883009	Coffee
	883045	Toast
	883046	Platinum
	830899	Stainless Steel
11		Glass & Frame Assembly
	883001	White
	883005	New Avocado
	883004	Golden Harvest
	883002	Almond
	883003	Coffee
	883047	Toast
	883048	Platinum
	833000	Stainless Steel
12	830736	Switch, Light (Includes 90825 Hex Nut)
15	830784	Motor, Blower
16	830738	Switch, Motor
17	830739	Bracket, Speed Control
18	830752	Cover, Wiring Box
19	830433	Knob, Control (2)
21	830865	Filter, Grease (2)
23	830892	Screw, Thumb (3)
24	830271	Bushing, Split
26	830462	Washer, No. 8 (4)
28	830898	Nameplate
29	830841	Screw, 10-32 x 3/8 Green (Ground)

Following Parts Not Illustrated

LITERATURE PARTS

LIT830735	Order Blank, Filter
LIT830872	Instructions, Installation & Operating
LIT980686	List, Repair Parts