



Quick Connect Plugs


P1 through P10 for oven controls

P21 through P25 for cooktop



Cooktop Wiring Diagram

NOTE: Schematic shows oven door open and elements off.



LEGEND

																	
Connection	No Connection	On Some Models	In-Line Connection	Connector P2, Position 1	Circuitry Enclosed Within	Terminals	Single Switch	Thermal Switch (opens on heat rise)	Thermal Switch (closes on heat rise)	Resistor or Element	Motor	Incandescent Light	Non-resettable Fuse	Thermistor	Indicator Light	Triac	Thermo Fuse