

ACTIVATING THE SERVICE DIAGNOSTIC MODES

- NOTES:**
- Entering Diagnostics mode will cancel any active oven operation.
 - Enter the Diagnostics mode only after the oven is cool.

RESISTANCES

Component	Pinout	Resistance or Voltage
Door position switch	P7-4 to P7-5	2 VDC with door open 0 VDC with door closed
Oven light	P5-4 to WH (Neutral) P6-3	0-40 Ω nominal
Thermo fuse	P1-3 to P2-4	Closed circuit (normal)
Oven sensor	P10-1 to P10-2	1000-1200 Ω at room temperature
Bake element	P1-4 to P3-1/P3-2	10-40 Ω nominal
Broil element	P1-1 to P3-1/P2-1	10-40 Ω nominal
Warming drawer sensor	P10-3 to P10-4	1000-1200 Ω at room temperature
Warming drawer element	P4-2 to WH (Neutral) P6-3	15-20 Ω nominal
Convection fan motor	P5-2 to WH (Neutral) P6-3	85-90 Ω
Convection element	P2-3 to WH (Neutral) P6-3	16 Ω nominal
Limiter switches	Term 2B or S to Term 1B or H	Normal = Infinite resistance
	Term Single - 1A', Dual - 4/4A or 3/1, Triple - P1 to Term 2A or 2	Normal = 0 resistance

IMPORTANT: Electrostatic discharge may cause damage to machine control electronics. Refer to online Tech Sheet for additional information.

Check for proper voltage by completing the following steps:

- 1. Disconnect the power or unplug the appliance.
- 2. Connect voltage measurement equipment to proper connectors.
- 3. Plug in appliance or reconnect power and confirm voltage reading.
- 4. Disconnect the power or unplug the appliance.

WIRE DIAGRAM

